

# INTRODUCTION

Congratulations on your purchase of the Yamaha XJ750J. This model represents many years of Yamaha experience in the production of fine sporting, touring, and pacesetting racing machines. You can now appreciate the high degree of craftsmanship and reliability that have made Yamaha a leader in these fields.

This manual will provide the owner with a good basic understanding of one operation and basic maintenance of this vehicle. If you have any questions regarding the operation or maintenance of your motorcycle, please consult your Yamaha dealer.

## NOTICE:

Some data in this manual may become outdated due to improvements made to this model in the future. If there is any question concerning this manual, consult your nearby Yamaha dealer.

This Yamaha Motorcycle in its design and manufacture fully complies with the emissions standard for clean air applicable at the date of manufacture. Yamaha has met these standard without reducing the motorcycle's performance or economy of operation. To maintain these high standard, it is important that you and your dealer pay close attention to the recommended maintenance schedules and operating instructions contained within this manual.

SERVICE DEPT.  
INTERNATIONAL DIVISION  
YAMAHA MOTOR CO., LTD.

## CONTENTS

LOCATION OF THE "CAUTION AND SPECIFICATION LABELS" .....	1
DESCRIPTION .....	3
MOTORCYCLE IDENTIFICATION....	4
CONTROL FUNCTIONS .....	6
PRE-OPERATION CHECKS.....	23
OPERATION AND IMPORTANT RIDING POINTS .....	33
PERIODIC MAINTENANCE AND MINOR REPAIR .....	40
CLEANING AND STORAGE.....	92
MISCELLANEOUS.....	95
SPECIFICATIONS .....	96
WARRANTY INFORMATION.....	100
MAINTENANCE RECORD .....	101
WIRING DIAGRAM.....	105

IMPORTANT: PLEASE READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING THIS MOTORCYCLE. DO NOT ATTEMPT TO OPERATE THIS MOTORCYCLE UNTIL YOU HAVE ATTAINED A SATISFACTORY KNOWLEDGE OF ITS CONTROLS AND OPERATING FEATURES AND UNTIL YOU HAVE BEEN TRAINED IN SAFE AND PROPER RIDING TECHNIQUES. REGULAR INSPECTIONS AND CAREFUL MAINTENANCE, ALONG WITH GOOD RIDING SKILLS, WILL ENSURE THAT YOU SAFELY ENJOY THE CAPABILITIES AND THE RELIABILITY OF YOUR MOTORCYCLE.

## **XJ750 OWNER'S MANUAL**

1st Edition - November 1981

2nd Printing - January 1984

3rd Printing - February 1985 JEM

ALL RIGHTS RESERVED BY  
YAMAHA MOTOR CORPORATION, U.S.A.  
CYPRESS, CALIFORNIA 90630

**LIT-11626-02-84**



**IMPORTANT:**

**PLEASE READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING THIS MOTORCYCLE.**

**DO NOT ATTEMPT TO OPERATE THIS MOTORCYCLE UNTIL YOU HAVE ATTAINED A SATISFACTORY KNOWLEDGE OF ITS CONTROLS AND OPERATING FEATURES AND UNTIL YOU HAVE BEEN TRAINED IN SAFE AND PROPER RIDING TECHNIQUES.**

**REGULAR INSPECTIONS AND CAREFUL MAINTENANCE, ALONG WITH GOOD RIDING SKILLS, WILL ENSURE THAT YOU SAFELY ENJOY THE CAPABILITIES AND THE RELIABILITY OF THIS MOTORCYCLE.**

YAMAHA MOTOR CORPORATION U.S.A.  
ALL RIGHTS RESERVED BY  
YAMAHA MOTOR CORPORATION U.S.A.  
2nd Printing - January 1984  
1st Edition - November 1983  
YAMAHA MOTOR CORPORATION U.S.A.  
CYPRESS, CALIFORNIA 94530  
LT-1100-02-84



Particularly important information is distinguished in this manual by the following notations.

**NOTE:** A NOTE provides key information to make procedures easier or clearer.

**CAUTION:** A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle.

**WARNING:** A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

**NOTE:** \_\_\_\_\_  
This manual should be considered a permanent part of this motorcycle and should remain with it even if the motorcycle is subsequently sold.

---


## **SAFETY WARNINGS:**

- 1. Traffic regulations vary from state to state. Study the regulations in your state before riding this motorcycle.**
- 2. This motorcycle is designed for on-road use only. It is not suitable for off-road use.**
- 3. GASOLINE IS HIGHLY FLAMMABLE:**
  - \* Always turn off the engine when refuelling.**
  - \* Take care not to spill any gasoline on the engine or exhaust pipe(s)/muffler(s) when refuelling.**
  - \* Never refuel while smoking or in the vicinity of an open flame.**
- 4. If you should swallow some gasoline, inhale a lot of gasoline vapor, or allow some gasoline to get in your eye(s), see your doctor immediately. If any gasoline spills on your skin or clothing, immediately wash it with soap and water and change your clothes.**
- 5. Always turn off the engine before leaving the motorcycle unattended, and do not forget to remove the ignition key. When parking the motorcycle, note the following:**
  - \* The engine and exhaust pipe(s)/muffler(s) may be hot. Park the motorcycle in a place where pedestrians or children are not likely to touch the motorcycle.**

- \* Do not park the motorcycle on a lope or soft ground; the motorcycle may overturn.**
- 6. When transporting the motorcycle in another vehicle, be sure it is kept upright and that the fuel cock(s) is turned to the "ON" or "RES" position (for vacuum type)/"OFF" position (for manual carburetor or fuel tank.**
- 7. Never start your engine or let it run for any length of time in a closed area. The exhaust fumes are poisonous and may cause loss of consciousness and death within a short time. Always operate your motorcycle in an area with adequate ventilation.**
- 8. Always wear a helmet, gloves, trousers (tapered around the cuff and ankle so they do not flap), and a brightly colored jacket.**
- 9. This motorcycle is designed for use as a two-wheeled vehicle capable of carrying a rider and a passenger. The total weight of the rider, accessories, and cargo must not exceed the maximum load limit. (See page 27.)**




## LOCATION OF THE "CAUTION AND SPECIFICATION LABELS"



①

MFD. BY YAMAHA MOTOR CO., LTD., (Month/Year) GVWR xxx LBS.  
 GAWR FRONT - xxx LBS. WITH xxxxx TIRE, xxxxx RIM,  
 AT xx PSI COLD. REAR - xxx LBS. WITH xxxxx TIRE,  
 xxxxx RIM, AT xx PSI COLD.  
 THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE  
 SAFETY STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE  
 SHOWN ABOVE.  
 VEHICLE IN NO. xxxxxx (17 digits)  
 TYPE CLASSIFICATION ... MOTORCYCLE

②

VEHICLE EMISSION CONTROL INFORMATION		THIS VEHICLE CONFORMS TO U.S. EPA AND CALIFORNIA REGULATIONS APPLICABLE TO 1987 MODEL YEAR NEW MOTORCYCLES
ENGINE FAMILY: CYA 075044A0 DISPLACEMENT: 748 cc EXHAUST EMISSION CONTROL SYSTEM EM		
ENGINE TUNE UP SPECIFICATIONS AND ADJUSTMENTS AT NORMAL OPERATING TEMPERATURE PUT VEHICLE IN THE UPRIGHT POSITION, TRANSMISSION IN NEUTRAL, AND WARM UP ENGINE		
ITEM	SPEC	INSTRUCTIONS
1	IGNITION TIMING 7° BTDC AT IDLE SPEED	NO ADJUSTMENT
2	IDLE SPEED (RPM) 1050	ADJUST THROTTLE STOP SCREW
3	IDLE MIXTURE	NO ADJUSTMENT
4	VALVE CLEARANCE (MM) IN 0.11 ~ 0.15 EX 0.16 ~ 0.20	SEE SERVICE MANUAL
5 SPARK PLUG NGK BP7ES, SPARK PLUG GAP (MM) 0.7 ~ 0.8		
FUEL SPECIFICATIONS		ENGINE LUBRICANT SPECIFICATIONS
GASOLINE GRADE, REGULAR (LEADED) RESEARCH OCTANE 91 MIN		ENGINE OIL, SAE 20W/40 (ABOVE 5°) TYPE "SE" SAE 10W/30 (BELOW 15°)
YAMAHA MOTOR CO., LTD. 		

③

**CAUTION****(BATTERY REMOVAL AND INSTALLATION)**

1. Disconnect breather pipe before removing battery.
2. After installing battery, be sure to connect breather pipe into place.

④

USE HYPOID GEAR OIL

SAE #80

YAMAHA MOTOR CO., LTD.




⑤

**CAUTION (AIR SUSPENSION)**

1. Containing highly compressed air.
2. Use only air or nitrogen gas, other gases may cause explosion.
3. Do not incinerate.
4. Servicing requires special knowledge and tools. Read owner's manual before operating this suspension.



## DESCRIPTION




- |                            |                            |
|----------------------------|----------------------------|
| 1. Rear flasher light      | 12. Seat                   |
| 2. Rear shock absorber     | 13. Tail/Brake light       |
| 3. Fuel tank               | 14. Change pedal           |
| 4. Front flasher light     | 15. Front wheel            |
| 5. Front fender            | 16. Clutch level           |
| 6. Brake pedal             | 17. Tachometer             |
| 7. Footrest                | 18. Speedometer            |
| 8. Silencer                | 19. Brake lever            |
| 9. Rear wheel              | 20. Throttle grip          |
| 10. Headlight              | 21. Right handlebar switch |
| 11. Theft-Protection chain | 22. Left handlebar switch  |



# MOTORCYCLE IDENTIFICATION

## Frame serial number


The frame serial number is stamped into the right side of the steering head pipe.



1. Frame serial number

## Engine serial number

The engine serial number is stamped into the elevated part of the right rear section of the engine.




1. Engine serial number

## NOTE:

The first three digits of these numbers are for model identification; the remaining digits are the unit production number. Keep a record of these numbers for reference when ordering parts from your Yamaha dealer.

## Vehicle identification number

The vehicle identification number is stamped on the label attached to the steering head pipe.



1. Vehicle identification number

## NOTE: \_\_\_\_\_

The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your state.


---



# CONTROL FUNCTIONS

## Main switch

Functions of the respective switch positions are as follows:



### ON:

Electrical circuits are switched on, and the headlight, meter light, and taillight come on. The engine can be started. The key cannot be removed in this position. Refer to "Computerized monitor system" (Page 7) for proper operation.

### OFF:

All electrical circuits are switched off. The key can be removed in this position.

### LOCK:

The steering is locked in this position, and all electrical circuits are switched off. The key can be removed in this position. Refer to "Steering lock" (Page 16) for proper operation.

### PARKING:


The steering is locked in this position, and the taillight comes on but all other circuits are off. The key can be removed in this position.

### NOTE:

Always turn the main switch to "OFF" or "LOCK" position and remove the key when the motorcycle is unattended.



## Indicator lights



1. "TURN" indicator light
2. "HIGH BEAM" indicator light
3. "NEUTRAL" indicator light

### "TURN" indicator light (orange):

This indicator flashes when the turn switch is "ON".

### "HIGH BEAM" indicator light (blue):


This indicator lights when the headlight high beam is used.

### "NEUTRAL" indicator light (green):

This indicator lights when the transmission is in neutral.

## Computerized monitor system

This system monitors seven separate functions and will warn you of any malfunction if encountered until it is fixed. In addition, the fuel gauge in this system indicates the amount of fuel in the tank.



1. "WARNING" light (red)
2. Display panel
3. "WARNING CONTROL" switch
4. "CHECK" switch

## Operation

### NOTE:

Before starting out on the road, check the motorcycle conditions using computerized monitor system.

1. When the main switch is turned on, all seven liquid crystal displays (LCDs) come on, with the bottom fuel display (■■■■) indicating the amount of fuel in the tank.
2. When the engine is started, the system begins its scan of the motorcycle conditions. From top to bottom all the LCDs flash on and then off in sequence. If any one condition is found improper or inadequate, the red warning light will begin flashing and the LCD for the area in question will remain displayed.

#### **WARNING:**

If any LCD remains displayed or the warning light flashes on, correct the problem immediately. If the correction is beyond your capability, ask a Yamaha dealer or other qualified mechanic.

3. Warning light operation can be controlled by the warning control switch. If the control switch is pushed once, the warning light flow will change from a flashing to a steady one. If pushed again, the glow will go out completely. Still another push on the switch brings back the warning light operation all over again.

#### **NOTE:**

1. This switch operates only when a malfunction is displayed on an LCD.
2. Even if the warning light is made to glow steady or to go out, it will begin flashing on with another malfunction.
4. The entire monitoring system condition can be checked by pushing the check switch. The system will scan through the seven areas in sequence, just as when the engine was first started, to assure the rider that the system is functioning properly.



**WARNING:**

If the system does not function properly, ask a Yamaha dealer or other qualified mechanic immediately.

**Display panel****STND:**

This indicator is displayed when the side stand is extended. Be sure to retract it before starting out on the road.

**BRK:**

This indicator is displayed when the brake fluid level is below specification in the front brake master cylinder. In this case, ask a Yamaha dealer or qualified mechanic immediately.

**WARNING:**

Do not run the motorcycle with a low brake fluid level for a long time or at high speeds.

**OIL:**

This indicator is displayed when the engine oil level is low. If it remains displayed or keeps flickering while riding, add engine oil at the first opportunity.

**WARNING:**

Do not run the motorcycle with a low engine oil level for a long time or at high speeds.

**BATT:**

This indicator is displayed when the battery fluid level is low. If it remains displayed, add distilled water at the first opportunity.

**CAUTION:**

Continuous riding with a low battery fluid level will damage the battery.



**HEAD:**

This indicator is displayed when the headlight bulb is burned out. If it remains displayed, have it replaced and correctly adjusted at the first opportunity.

**TAIL:**

This indicator is displayed when the taillight and/or brake light bulbs are burned out. If it remains displayed, have it replaced at the first opportunity.

**FUEL:**

This indicator is displayed when the fuel level is low. If it remains displayed or keeps flickering while riding, add fuel at the first opportunity.

**GENERAL CAUTION:**


Failure to observe any of the following "mustn'ts" may result in malfunction of the microcomputer or damage to the electrical circuit.

1. Taillight, brake light and other bulbs of wattage other than specified mustn't be used.
2. Extra electric accessories mustn't be connected to the computerized monitor system circuit (ex: Taillight, headlight etc.).
3. The instrument panel mustn't be subjected to any water splashes or steam from underneath.
4. The display panel mustn't be pressed hard or given any shock.
5. A magnet or other magnetized objects mustn't be put near the display panel.

## Speedometer

The odometer and trip odometer are built into the speedometer. The trip odometer can be reset to "0" with the reset knob.

Use the odometer and fuel level gauge to estimate how far you can ride on a tank of fuel before going to "EMPTY". This information will enable you to plan fuel stops in the future.



1. Reset knob    2. Odometer    3. Trip odometer

## Tachometer


The tachometer is provided so the rider can keep engine speed within the ideal power range.

This model is provided with an electric tachometer.

### **WARNING:**

Do not operate in the red zone.


Red zone: 9,500 r/min and above.



1. Red zone



## Handlebar switches:



- |                             |                         |
|-----------------------------|-------------------------|
| 1. "LIGHTS" (Dimmer) switch | 4. "ENGINE STOP" switch |
| 2. "TURN" switch            | 5. "START" switch       |
| 3. "HORN" switch            | 6. "AUX LAMP" switch    |

### "LIGHTS" (Dimmer) switch

Turn to the "HI" position for the high beam and to the "LO" position for the low beam.

### "TURN" switch

This model is equipped with a turn indicator system that is self-cancelling. To signal a right-hand turn, push down the switch to the right. To signal a left-hand turn, push down the

switch to the left. Once the switch is released it will return to the center position. To cancel the signal push down the switch after it has returned to the center position. If the switch is not cancelled by hand, it will self-cancel after the motorcycle has travelled about 10 seconds or approximately 150 meters (490 feet) whichever is greater. The self-cancelling mechanism only operates when the motorcycle is moving; thus the signal will not self-cancel while you are stopped at an intersection.

### "HORN" switch

Press the switch to sound the horn.

### "ENGINE STOP" switch

The engine stop switch is a safety device for use in an emergency such as when the motorcycle overturn or when trouble occurs in the throttle system. The engine will not start when the engine stop switch is turned to "OFF". In case of an emergency, turn the switch to "OFF".



### **"START" switch**

To start the engine, push the starter switch.

### **CAUTION:**

See starting instructions prior to starting engine.

### **"AUX LAMP" switch**


To light the auxiliary low beam light, turn the switch to the "ON" position.

### **Clutch lever**

The clutch lever is located on the left handlebar, and the starting circuit cut-off switch is incorporated in the clutch lever holder. Pull the clutch lever to the handlebar to disengage the clutch, and release the lever to engage the clutch. The lever should be pulled rapidly and released slowly for smooth starts. (Refer to the engine starting procedures for the starting circuit cut-off switch functions.)

### **Change pedal**

The gear ratios of the constant-mesh 5-speed transmission are ideally spaced. The gears can be shifted by using the change pedal on the left side of the engine.



N. Neutral

### **Front brake lever**

The front brake lever is located on the right handlebar. Pull it toward the handlebar to activate the front brake.

### Rear brake pedal

The rear brake pedal is on the right side of the motorcycle. Press down on the brake pedal to activate the rear brake.

### Fuel tank cap

To open:


Insert the key and turn it clockwise 1/4 turn. The lock will be released and the fuel tank cap can be opened.

To close:

Push the tank cap into position with the key inserted. To remove the key, turn it counter-clockwise to the original position.

### NOTE:

This tank cap cannot be closed unless the key is in the lock. The key cannot be removed if the cap is not locked properly.




1. Open

### WARNING:

Do not overfill the fuel tank. Avoid spilling fuel on the hot engine. Do not fill the fuel tank above the bottom of the filler tube or it may overflow when the fuel heats up later and expands.





### Fuel cock

The negative pressure fuel cock supplies fuel from the tank to the carburetor(s) and also filters the fuel. The fuel cock has the following three positions:


**ON:** With the lever in this position fuel flows if the engine is running but stops if the engine is not running.

**RES:** This indicates "RESERVE". If you run out of fuel while riding, move the lever

to "PRI" and switch to "RES" position after starting the engine. Then, fill the tank at the first opportunity.

### NOTE:

In the "ON" and "RES" positions the cock works on pressure from the engine turning over. If the line connecting the cock to the carburetor intake manifold is not connected or has a leak, the cock will not function properly.





**PRI:** This indicates "PRIME". With the fuel cock in this position fuel flows whether the engine is running or not. If the fuel tank is completely empty, refill the tank, prime the carburetor in this position, and then switch to the "ON" position after starting the engine.

### **Starter lever (CHOKE)**

The starter lever is located on the left handlebar.


Starting a cold engine requires a richer fuel mixture. In such a case, turn the starter lever in the left direction.

After the engine is warm, turn the lever to its original position.

### **NOTE:** \_\_\_\_\_

Refer to "Starting and warming up a cold engine" for proper operation.

---





1. Starter lever

### **Steering lock**

The steering is locked when the main switch is in the "LOCK" position. To lock the steering, turn the handlebars all the way to the right or left. Give one push to the key at the "OFF" position; then turn it counterclockwise to the "LOCK" position and remove the key. To release the lock, then the key clockwise.

## WARNING:

Never turn the key to "LOCK" when the motorcycle is moving.




1. Push

2. Release

3. Turn

## Seat lock


To open the seat lock, insert the key in the lock and turn it counterclockwise. Then push down the levers on both sides.



1. Open

In reinstalling the seat, insert the lobes on the seat front into the receptacles on the frame, then push down the seat at the end. After making sure the seat is securely fitted, turn the key clockwise to the center position to lock.






### Helmet holder

To open the helmet holder, insert the key in the lock and turn it clockwise.

To lock the helmet holder, replace the holder in original position.

### **WARNING:**

Never ride with a helmet in the helmet holder. It could interfere with rear wheel movement, causing loss of control and possible an accident.




1. Helmet holder

2. Open



### Adjustable handlebars

This model is equipped with handlebars which are capable of vertical and horizontal adjustment to suit the rider's position and preference. For the adjustment procedure, see page 64.




1. Vertical adjustment 2. Horizontal adjustment

### Front forks

The air pressure preload and the damping of the front fork can be adjusted to suit motorcycle load (ex: optional accessories etc.) and riding conditions.

Refer to page 71 for proper adjustment procedures.




1. Air valve 2. Damping adjuster

## Rear shock absorber

The spring preload and the damping force can be adjusted to suit motorcycle's load (ex: optional accessories etc.) and riding conditions. Refer to page 73 for proper adjustment procedures.

### **WARNING:**

Always adjust the shock absorbers to the same position on each side. Uneven adjustment can cause poor handling and loss of stability.




1. Damping adjuster    2. Softest    3. Stiffest

## Theft protection chain

This chain is designed for theft protection of your motorcycle and is placed under the left-hand side cover.

Take out and use the chain as follows:

1. To remove the chain from the frame projection, insert the main switch key in the lock and turn it clockwise.





1. Open



2. Fasten the chain to a suitable fixed object.

To clock the chain, insert one end into the other. The chain automatically locks. To unfasten the chain, insert the main switch key in the lock and turn it clockwise.



**NOTE:**

To replace the chain, make sure that the chain lock is securely fitted over the frame projection.


**WARNING:**

Before starting, make sure that your motorcycle is unlocked.



## Sidestand


This model is equipped with an ignition circuit cutoff system. The motorcycle can be ridden only when the sidestand is up. The sidestand is located on the left of the frame. (Refer to Page 33 for an explanation of this system.)



1. Side stand

## Adjustable footrest

This model features adjustable footrests that can be moved back and forth so the best riding position can be determined according to rider's build and preference. For the adjusting procedure, see page 62.



## PRE-OPERATION CHECKS (DAILY)

Before using this motorcycle check the following points:

No.	Item	Routine	Page
1	Brakes (Front)	Check operation, free play, fluid level and brake fluid leakage. Top-up with DOT #3 brake fluid if necessary.	25 ~ 26 54 ~ 55, 57 ~ 59
2	Brake (Rear)	Check operation, free play and adjust if necessary	25 ~ 26, 55 ~ 59
3	Clutch	Check operation condition and free play. Adjust if necessary.	26, 60
4	Engine oil	Check engine oil level, add oil if necessary.	26, 49 ~ 51
5	Final gear oil	Check for leakage visually.	27, 51 ~ 52
6	Throttle	Check for smooth operation. Adjust if necessary.	26, 61
7	Battery	Check fluid level, top-up with distilled water if necessary.	32, 77 ~ 78
8	Lights/Signals	Check operation.	31, 79 ~ 84
9	Wheels/Tires	Check tire pressure, wear damage.	27 ~ 31, 84 ~ 90
10	Fittings/Fasteners	Check all chassis fittings and fasteners. Adjust, if necessary.	31, 48



**NOTE:** \_\_\_\_\_

Pre-operation checks should be made each time the motorcycle is used. Such an inspection can be accomplished in a very short time, and the added safety it assures is more than worth the time involved.

---

**WARNING:** \_\_\_\_\_

1. The engine, exhaust pipe(s), and muffler(s) will be very hot after the engine has been run. Be careful not to touch them or to allow any clothing item to contact them during inspection or repair.
  2. If any item in the PRE-OPERATION CHECK is not working properly, have it inspected and repaired before operating the motorcycle.
-

## **Brakes (See page 54 for more detail)**

### **1. Brake lever and brake pedal**

Check for correct play in the front brake lever and rear brake pedal. Make sure they are working properly. Check the brakes at low speed shortly after starting out.

#### **WARNING:**

A soft, spongy feeling in the brake lever (and/or brake pedal) indicates a failure in the brake system. Do not operate the motorcycle until the failure in the brake system is corrected. Ask a Yamaha dealer or other qualified mechanic for immediate repairs. A soft, spongy feeling could indicate an hazardous condition in the brake system.

### **2. Brake fluid (Front)**

Check the brake fluid level with the computerized monitor system. If this indicator is displayed when the brake fluid level is below specification in the brake master cylinder. Add fluid if necessary.

#### **WARNING:**

In this case, ask a Yamaha dealer or qualified mechanic immediately. Do not run the motorcycle with a low brake fluid for a long time or at high speeds.

Recommended brake fluid: DOT #3

### **3. Checking the disc pads**

Refer to page 57.

### **4. Checking the rear brake shoe**

Refer to page 57.



**NOTE:** \_\_\_\_\_

When this brake service is necessary, have a Yamaha dealer or other qualified mechanic replace the pads.

**Brake fluid leakage**

Apply each brake for a few minutes. Check to see if any brake fluid leaks out from pipe joints or the master cylinder.

**WARNING:** \_\_\_\_\_

If brake fluid leakage is found, ask a Yamaha dealer or other qualified mechanic for immediate repairs. Such leakage could indicate a hazardous condition in the brake system.

**Clutch (See page 60 for more detail)**

Check for correct play in the clutch lever and make sure the lever operates properly.

If the play is incorrect, make an adjustment.


**Throttle grip (See page 61 for more detail)**

Turn the throttle grip to see if it operates properly and if the play is normal. Make certain the throttle springs closed when released.

**Engine oil (See page 49 for more detail)**

Make sure the engine oil is at the specified level. Add oil as necessary.

**Recommended oil:**



### Final gear oil (See page 51 for more detail)

Make sure the final gear oil is at the specified level. Add oil as necessary.

Recommended oil:  
SAE 80 API GL-4 Hypoid gear oil

If desired, an SAE 80W90 hypoid gear oil may be used for all conditions.

### NOTE:

"GL-4" is a quality and additive rating. "GL-5" or "GL-6" rated hypoid gear oils may also be used.

### Tires

Check the tire pressure and check the tires for wear.

	FRONT	REAR
XJ750J WEIGHT with oil and full fuel tank	111 kg (245 lb)	125 kg (276 lb)
Standard tire	Bridgestone/ Dunlop 3.25 H 19-4PR	Bridgestone/ Dunlop 130/90-16 67 H
Maximum load limit*	166 kg (366 lb)	300 kg (661 lb)
Cold tire pressure		
Up to 90 kg (198 lb) load**	177 kPa (1.8 kg/cm <sup>2</sup> , 26 psi)	196 kPa (2.0 kg/cm <sup>2</sup> , 28 psi)
90 kg (198 lb) load ~ 230 kg (507 lb) load ** (Maximum load)	196 kPa (2.0 kg/cm <sup>2</sup> , 28 psi)	225 kPa (2.3 kg/cm <sup>2</sup> , 32 psi)
High speed riding	196 kPa (2.0 kg/cm <sup>2</sup> , 28 psi)	225 kPa (2.3 kg/cm <sup>2</sup> , 32 psi)
Minimum tire tread depth	0.8 mm (0.03 in)	0.8 mm (0.03 in)

\* Total weight of motorcycle with accessories, etc.

\*\* Total weight of accessory, etc. excepting motorcycle.



## Tubeless tires and aluminum wheels

This motorcycle is equipped with aluminum wheels designed to be compatible with either tube or tubeless tires.

Tubeless tires are installed as standard equipments.


### WARNING:

Do not attempt to use tubeless tires on a wheel designed for use only with tube-type tires. Tire failure and personal injury may result from sudden deflation.

Tube-type Wheel	→ Tube-type Tires only
Tubeless type Wheel	→ Tube-type or Tubeless tires

### WARNING:

When using tube-type tires, be sure to install the proper tube.



To insure maximum performance, long service, and safe operation, note the following precautions:

1. Always maintain proper air pressure as described in the chart page 27.
2. Check tire pressure before riding. Adjust as necessary.
3. Before operation, always check the tire surfaces for wear and/or damage; look for cracks, glass, nails, metal fragments, stones, etc. Correct any such hazard before riding.
4. Always inspect the aluminum wheels before a ride. Place the motorcycle on the centerstand and check for cracks, bends, or warpage of the wheels. If any abnormal condition exists in a wheel, consult your Yamaha dealer or other qualified mechanic. Do not attempt even small repairs to the wheel. If a wheel is deformed or cracked, it must be replaced.

5. Tires and wheels should be balanced whenever either one is changed or replaced. Failure to have a wheel assembly balance can result in poor performance, adverse handling characteristics, and shortened tire life.
6. After installing a tire, ride conservatively to allow the tire to seat itself on the rim properly. Failure to allow proper seating may cause tire failure resulting in damage to the motorcycle and injury to the rider.
7. After repairing or replacing a tire, check to be sure the valve stem lock nut is securely fastened. If not, torque it as specified.

Tightening torque:

1.5 Nm (0.15 m·kg, 1.1 ft·lb)




The standard equipment tires originally fitted to the XJ750J are suited to normal riding and touring. They are not suited for sustained high speed running or racing and must not be used for such purposes. Consider your riding

skill, road and weather conditions, and correct weight distribution when loading your motorcycle. Securely pack your heaviest items close to the center of the motorcycle.

#### **WARNING:**

1. This motorcycle is not designed to pull a trailer or to be attached to a sidecar. The accessories you choose for your motorcycle should be designed specifically for it and should be securely mounted in such a fashion as to maintain the inherent stability of the original design as much as possible. Yamaha has a full line of sport and touring accessories designed specifically for this motorcycle. Please consider them before making a purchase. Use of non-approved accessories may cause loss of handling stability and riding safety. Consult a Yamaha dealer or other qualified mechanic regarding the consequences of using such items.
2. Proper loading of your motorcycle is important for the handling, braking, and other performance and safety characteristics of your motorcycle. **NEVER OVERLOAD YOUR MOTORCYCLE.** Make sure the total weight of the accessories, and etc., does not exceed the maximum load limits. Operation of an overloaded motorcycle could cause tire damage, and accident, and injury.



If a tire tread shows crosswise lines, it means that the tire is worn to its limit. Replace the tire.

#### **WARNING:**

It is dangerous to ride with a worn-out tire. When a tire tread begins to show lines, have your Yamaha dealer or other qualified mechanic replace the tire immediately. Brake pad replacement, tire, and related wheel parts replacement should be left to a Yamaha Service

Technician or other qualified mechanic. If you must change your own tire, be sure to use proper tools and procedures as described in the Tubeless Tire and Wheel Manual available from a Yamaha dealer or other qualified mechanic.

---

#### **Fittings/Fasteners**

Always check the tightness of chassis fittings and fasteners before a ride. Use the chart on page 48 to find the correct torque.

#### **Lights and signals**

Check the headlight, flasher lights, taillight, brake light, meter lights and all the indicator lights to make sure they are in working condition.

#### **Switches**

Check the operation of the headlight switch, turn switch, brake light switch, horn switch, main switch, etc.



### Battery (See page 77 for more detail)

Check fluid level and top-up if necessary.

Use only distilled water if refilling is necessary.

### **CAUTION:**

Continuous riding with a low battery fluid level will damage the battery.

### Fuel (See page 8 for more detail)

Check the fuel level with the computerized monitor system. If this indicator is displayed, the fuel level is low. Add fuel at the first opportunity.

### Recommended gasoline:

Regular gasoline

### Fuel tank capacity

Full: 17 L (3.7 Imp gal, 4.5 US gal)

Empty (displayed):

3.5 L (0.8 Imp gal, 0.9 US gal)

## OPERATION AND IMPORTANT RIDING POINTS

### **WARNING:**

Before riding this motorcycle, become thoroughly familiar with all operating controls and their function. Consult a Yamaha dealer or other qualified mechanic regarding any control or function you do not thoroughly understand.

### **CAUTION:**

1. Be careful where you store personal items on the motorcycle. Avoid blocking the air cleaner intake or performance will suffer.
2. Be careful not to put anything near the battery and its terminals. Electrical failure and acid corrosion may result.

### **WARNING:**

Never start your engine or let it run for any length of time in a closed area. The exhaust fumes are poisonous and can cause loss of consciousness and death within a short time. Always operate your motorcycle in an area with adequate ventilation.

### Starting and warming up a cold engine

### **NOTE:**

This motorcycle is equipped with a starting and an ignition circuit cutoff switch.

1. The engine can be started only under the following conditions:
  - a. The transmission is in neutral.
  - b. The sidestand is up, the transmission is in gear, and the clutch is disengaged.
2. The motorcycle can be ridden only when the sidestand is up.



TURN MAINSWITCH TO "ON" AND  
ENGINE STOP SWITCH TO "RUN".

IF TRANSMISSION IS IN NEUTRAL  
AND SIDESTAND IS DOWN.

PUSH STARTER SWITCH;  
ENGINE WILL START.

RETRACT SIDESTAND AND PUT  
TRANSMISSION IN GEAR.

MOTORCYCLE CAN BE RIDDEN.

IF TRANSMISSION IS IN GEAR  
AND SIDESTAND IS UP.

PULL IN CLUTCH LEVER AND PUSH  
STARTER SWITCH; ENGINE WILL START.

MOTORCYCLE CAN BE RIDDEN.

1. Turn the fuel cock to "ON".
2. Turn the ignition key to the "ON" position and the engine stop switch to "RUN".
3. Shift transmission into neutral.

**NOTE:**

When the transmission is in neutral, the neutral indicator light (green) should be on. If the light does not come on, ask a Yamaha dealer or other qualified mechanic to inspect it.

4. Move the starter (CHOKE) lever fully to the left and completely close the throttle grip.
5. Start the engine by pushing the starter switch.

**NOTE:**

If the engine fails to start, release the starter switch, then push the starter switch again. Pause a few seconds before the next attempt. Each cranking should be as short as possible to preserve battery energy. Do not crank the engine more than 10 seconds on each attempt.

6. After starting the engine, move the starter lever back. The starter operation periods differ with the ambient temperature, so refer to the following notes.

**NOTE:**

To see whether or not the engine is warm, see if engine responds normally to throttle with the starter moved back completely. To avoid the possibility of excessive exhaust emissions, never leave the starter circuit on longer than necessary.

The length of time the starter is used to start a cold engine depends upon the ambient temperature.

Warm ambient temperatures (above 10°C ~ 50°F) require about 25 seconds of starter use. Cold ambient temperatures (below 10°C ~ 50°F) require about 35 seconds with the starter fully open, then about 2.5 minutes with the starter in the half-open position.

To get maximum engine life, always "warm-up" the engine before starting off. Never accelerate hard with a cold engine!



### Starting a warm engine

The starter lever (CHOKE) is not required when the engine is warm.

### **CAUTION:**

See "Break-in section" prior to operating engine for the first time.

### Shifting and acceleration

This model has a 5-speed transmission. The transmission allows you to control the amount of power you have available at a given speed or while accelerating, climbing hills, etc. The use of the change pedal is shown in the illustration. (Page 13)

To shift into NEUTRAL, repeatedly depress the change pedal to the end of its travel (you will feel a stop when you are in first gear), then raise it slightly.

### To start out and accelerate:

1. Pull the clutch lever to disengage the clutch.
2. Shift into FIRST gear. The green neutral indicator light should go out.
3. Open the throttle gradually, and at the same time, release the clutch lever slowly.
4. At the recommended shift point shown in the table below, close the throttle, and at the same time pull in the clutch lever quickly.
5. Shift into SECOND gear. (Be careful not to shift into neutral.)
6. Open the throttle part way and gradually release the clutch lever.
7. Follow the same procedure when shifting to the next higher gear. Always shift gears at the recommended shift points.

### To decelerate:

1. Apply front and/or rear brakes to slow the motorcycle.
2. When the motorcycle reaches 20 km/h (12.5 mi/h), shift to first gear.

Any time the engine appears about to stall or runs very roughly, pull in the clutch and use the brakes to stop.

3. When motorcycle is almost completely stopped, shift to neutral.

The green neutral indicator light should come on.

### Recommended Shift Point

	Acceleration shift point km/h (mi/h)	Deceleration shift point km/h (mi/h)
1st → 2nd	23 (14)	20 (12.5)
2nd → 3rd	36 (22)	20 (12.5)
3rd → 4th	50 (31)	20 (12.5)
4th → 5th	60 (37)	20 (12.5)

### CAUTION:

1. Do not glide for long periods with the engine off, and do not tow the motorcycle a long distance. Even with gears in neutral, the transmission is only properly lubricated unless the engine is running. Inadequate lubrication may damage the transmission.
2. Always use the clutch when changing gears. The engine, transmission, and driveline are not designed to withstand the shock load of forced shifting and can be damaged by shifting without the clutch.



## Engine break-in

There is never a more important period in the life of your motorcycle than the period between zero and 1,000 km (600 mi). For this reason we ask that you carefully read the following material. Because the engine is brand new, you must not put an excessive load on it for the first 1,000 km (600 mi). The various parts in the engine wear and polish themselves to the correct operating clearances. During this period prolonged, full throttle operation or any condition which might result in excessive heating of the engine must be avoided.

### 1. 0 ~ 150 km (0 ~ 100 mi):

Avoid operating above 5,000 r/min.

Allow a cooling off period of 5 to 10 minutes after every hour of operation. Vary the speed of the motorcycle from time to time. Do not operate it at one, set throttle position.

### 2. 150 ~ 500 km (100 ~ 300 mi):

Avoid prolonged operation above 6,000 r/min. Allow the motorcycle to rev freely through the gears but do not use full throttle at any time.

### 3. 500 ~ 1,000 km (300 ~ 600 mi):

Avoid prolonged full throttle operation. Avoid cruising speeds in excess of 7,000 r/min.

### 4. 1,000 km (600 mi) and beyond:

Avoid prolonged full throttle operation. Avoid engine speeds in excess of 8,000 r/min. Vary speeds occasionally.

## CAUTION:

After 1,000 km (600 mi) of operation, be sure to replace the engine oil and filter element.

If any engine trouble should occur during the break-in period, consult a Yamaha dealer immediately or other qualified mechanic.

## Parking

When parking, stop the engine and remove the ignition key.

### **WARNING:**

The muffler and exhaust pipe are hot. Park the motorcycle in a place where pedestrians or children are not likely to touch the motorcycle. Do not park the motorcycle on a slope or soft ground; the motorcycle may overturn.



## PERIODIC MAINTENANCE AND MINOR REPAIR

Periodic inspection, adjustment and lubrication will keep your motorcycle in the safest and most efficient condition possible. Safety is an obligation of the motorcycle owner.

The most important points of motorcycle inspection, adjustment, and lubrication are explained in the following pages.

"Maintenance, replacement or repair of the emission control devices and systems may be performed by any repair establishment or individual using any part which is certified (if applicable)."

### **WARNING:**


If the owner is not familiar with motorcycle service, this work should be done by a Yamaha dealer or other qualified mechanic.

## PERIODIC MAINTENANCE

PROPER PERIODIC MAINTENANCE OF YOUR MOTORCYCLE IS IMPORTANT TO ITS GIVING YOU LONG, PLEASURABLE SERVICE: ESPECIALLY IMPORTANT ARE THE MAINTENANCE SERVICES RELATED TO EMISSIONS CONTROL. THESE CONTROLS NOT ONLY FUNCTION TO ENSURE CLEANER AIR BUT ARE ALSO VITAL TO PROPER ENGINE OPERATION AND MAXIMUM PERFORMANCE. IN THE FOLLOWING TABLES OF PERIODIC MAINTENANCE, THE SERVICE RELATED TO EMISSIONS CONTROL ARE GROUPED SEPARATELY. THESE SERVICES REQUIRE SPECIALIZED DATA, KNOWLEDGE, AND EQUIPMENT. YAMAHA DEALERS ARE TRAINED AND EQUIPPED TO PERFORM THESE PARTICULAR SERVICES.

## Tool kit

The service information included in this manual is intended to provide you, the owner, with the necessary information for completing some of your own preventive maintenance and minor repairs. The tools provided in the owner's tool kit are sufficient for most of these purposes, except that a torque wrench, however is also necessary to properly tighten nuts and bolts.



1. Tool kit

## NOTE:

If you do not have a torque wrench available during a service operation requiring one, take your motorcycle to a Yamaha dealer or other qualified mechanic to check the torque settings and adjust them as necessary.

## WARNING:

Modifications to this motorcycle not approved by Yamaha may cause loss of performance. Excessive emissions can render it unsafe for use. Consult a Yamaha dealer or other qualified mechanic before attempting any changes.



## PERIODIC MAINTENANCE EMISSION CONTROL SYSTEM

No.	Item	Remarks	Initial break-in		Thereafter every	
			1,000 km (600 mi) or 1 month	5,000 km (3,000 mi) or 7 months	4,000 km (2,500 mi) or 6 months	8,000 km (5,000 mi) or 12 months
1*	Valve clearance	Check and adjust valve clearance when engine is cold.		○		○
2	Spark plugs	Check condition. Adjust gap. Clean. Replace after initial 13,000 km (8,000 mi) or 18 months and thereafter every 12,000 km (7,500 mi) or 18 months.		○	○	Replace every 12,000 km (7,500 mi) or 18 months.
3*	Crankcase ventilation system	Check ventilation hose for cracks or damage. Replace if necessary.		○		○
4*	Fuel line	Check fuel hose and vacuum pipe for cracks or damage. Replace if necessary.		○		○
5*	Exhaust system	Check for leakage. Retighten as necessary. Replace gasket(s) if necessary.		○	○	
6*	Carburetor synchronization	Adjust synchronization of carburetors.		○	○	
7*	Idle speed	Check and adjust engine idle speed. Adjust cable free play if necessary.		○	○	

\* It is recommended that these items be serviced by a Yamaha dealer or other qualified mechanic.

### Spark plug inspection

The spark plug is an important engine component and is easy to inspect. The condition of the spark plug can indicate something of the condition of the engine.

Normally, all spark plugs from the same engine should have the same color on the white porcelain insulator around the center electrode. The ideal color at this point is a medium to light tan color for a motorcycle that is being ridden normally. If one spark plug shows a distinctly different color, there could be something wrong with the engine. For example, if the center electrode porcelain is very white, this color could indicate an intake tract air leak or carburetion problem for that cylinder. Do not attempt to diagnose such problems yourself. Instead, take the motorcycle to a Yamaha dealer or other qualified mechanic.

You should periodically remove and inspect the spark plug because heat and deposits will

cause any spark plug to slowly break down and erode. If electrode erosion becomes excessive, or if carbon and other deposits are excessive, you should replace the spark plug with one of the proper type.

Standard spark plug:

BP7ES (NGK)

W22EP (NIPPONDENSO)

Before installing any spark plug, measure the electrode gap with a wire thickness gauge and adjust it to specification.

Spark plug gap:

0.7 ~ 0.8 mm (0.028 ~ 0.032 in)

When installing the plug, always clean the gasket surface and use a new gasket. Wipe off any grime from the threads, and torque the spark plug properly.



Spark plug torque:

20 Nm (2.0 m·kg, 14 ft·lb)

**NOTE:**

If a torque wrench is not available when you are installing a spark plug, a good estimate of the correct torque is 1/4 to 1/2 turn past finger-tights. Have the spark plug torqued to the correct value as soon as possible with a torque wrench.

## GENERAL MAINTENANCE/LUBRICATION

No.	Item	Remarks	Type	Initial break-in		Thereafter every		
				1,000 km (600 mi) or 1 month	5,000 km (3,000 mi) or 7 months	4,000 km (2,500 mi) or 6 months	8,000 km (5,000 mi) or 12 months	16,000 km (10,000 mi) or 24 months
1	Engine oil	Warm-up engine before draining.	Refer to page 26	○	○	○		
2	Oil filter	Replace.	—	○	○		○	
3	Final gear oil	Replace.	Refer to page 27	○			○	
4*	Air filter	Clean with compressed air.	—		○		○	
5*	Brake system	Adjust free play. Replace pads if necessary. (Front) Replace shoes if necessary. (Rear)	—	○	○	○		
6*	Clutch	Adjust free play.	—	○	○	○		
7*	Control and meter cable	Apply chain lube thoroughly.	Yamaha chain and cable lube or SAE 10W30 motor oil	○	○	○		
8	Brake pedal and change pedal shaft pivots	Apply chain lube lightly.	Yamaha chain and cable lube or SAE 10W30 motor oil		○	○		



No.	Item	Remarks	Type	Initial break-in		Thereafter every		
				1,000 km (600 mi) or 1 month	5,000 km (3,000 mi) or 7 months	4,000 km (2,500 mi) or 6 months	8,000 km (5,000 mi) or 12 months	16,000 km (10,000 mi) or 24 months
9	Center and side stand pivots	Apply chain lube lightly.	Yamaha chain and cable lube or SAE 10W30 motor oil		○	○		
10*	Rear arm pivot bearing	Check bearings assembly for looseness. Moderately repack every 16,000 km (10,000 mi).	Medium weight wheel bearing grease					Repack
11*	Front fork oil	Drain completely. Refill to specification.	Yamaha fork oil 10wt or equivalent					○
12*	Steering ball bearing and races	Check bearings assembly for looseness. Moderately repack every 16,000 km (10,000 mi).	Medium weight wheel bearing grease		○	○		Repack
13*	Wheel bearings	Check bearings for smooth rotation. Replace if necessary.	—		○	○		
14	Battery	Check specific Gravity. Check breather pipe for proper operation.	—		○	○		

No.	Item	Remarks	Type	Initial break-in		Thereafter every		
				1,000 km (600 mi) or 1 month	5,000 km (3,000 mi) or 7 months	4,000 km (2,500 mi) or 6 months	8,000 km (5,000 mi) or 12 months	16,000 km (10,000 mi) or 24 months
15	Brake/Clutch lever pivot shaft	Apply chain lube lightly.	Yamaha chain and cable lube or SAE 10W30 motor oil		○	○		
16*	A.C. Generator	Replace generator brushes. Replace at initial 13,000 km (8,000 mi) and thereafter every 16,000 km (10,000 mi).	—					Replace


\* It is recommended that these items be serviced by a Yamaha dealer or other qualified mechanic.



## Torque specifications

(For a more complete list, refer to the Service Manual for this model.)

Use a torque wrench to tighten these items. It is recommended that these items be checked



A (Nut)	B (Bolt)	General torque specifications		
		Nm	m•kg	ft•lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94

occasionally, especially before a long trip. Always check the tightness of these items whenever they are loosened for any reason.

Item	Torque		
	Nm	m•kg	ft•lb
Spark plug	20	2.0	14.0
Engine drain plug	43	4.3	31.0
Oil filter bolt	15	1.5	11.0
Change pedal	8	0.8	5.8
Front engine mount bolts (upper)	42	4.2	30.0
Front engine mount bolts (lower)	42	4.2	30.0
Rear engine mount bolts (under)	70	7.0	50.0
Engine mount stay (front)	20	2.0	14.0
Steering pinch bolts	20	2.0	14.0
Shock absorber (top)	30	3.0	22.0
Front wheel axle	110	11.0	80.0
Front axle pinch bolt	20	2.0	14.0
Rear wheel axle	110	11.0	80.0
Rear axle pinch bolt	6	0.6	4.3
Final gear drain plug	23	2.3	17.0

## Engine oil

### 1. Oil level measurement

- a. Place the motorcycle on the center stand.  
Warm up the engine for several minutes.


#### NOTE:

Be sure the motorcycle is positioned straight up when checking the oil level; a slight tilt toward the side can produce false readings.

- b. With the engine stopped, check the oil level through the level window located at the lower part of the right side crankcase cover.

#### NOTE:

Wait a few minutes until the oil level settles before checking.




1. Level window 2. Maximum mark 3. Minimum mark

- c. The oil level should be between maximum and minimum marks. If the level is lower, add sufficient oil to raise it to the proper level.
- ### 2. Engine oil and oil filter replacement
- a. Start the engine and stop it after a few minutes of warm-up.
  - b. Place an oil pan under the engine and remove the oil filler cap.




- c. Remove the drain plug and drain the oil.



1. Engine drain plug

- d. Remove the oil filter bolt and filter element.



1. Oil filter cover

- e. Re-install the drain plug (make sure it is tight).

Drain plug torque:

43 Nm (4.3 m·kg, 31.0 ft·lb)


- f. Install the new oil filter element, new O-ring and filter cover, tighten the oil filter bolt.

Oil filter bolt:

15 Nm (1.5 m·kg, 11.0 ft·lb)

**NOTE:**

Make sure the O-ring is positioned properly.



- g. Add oil through the oil filler hole.

Periodic oil change:

2.5 L (2.2 Imp qt, 2.6 US qt)


With oil filter replacement:

2.8 L (2.5 Imp qt, 3.0 US qt)

Recommended oil: See page 26.

**CAUTION:**

Take care not to allow foreign material to enter the crankcase.



- h. After replacement of engine oil and/or oil filter, be sure to check for any oil leakage. The oil level indicator light should go off after the oil is filled.

**CAUTION:**

If the indicator light flickers or remains on, immediately stop the engine and consult a Yamaha dealer or other qualified mechanic.


**Final gear oil**

1. Oil level measurement
  - a. Place the motorcycle on a level place and place it on the centerstand. The engine should be cool (at atmospheric temperature).
  - b. Remove the oil filler cap and check the oil level whether it is to the hole brim. If it is not up to this level, replenish oil.

**CAUTION:**

Take care not to allow foreign material to enter the final gear case.






1. Final gear oil      2. Correct oil level

## 2. Gear oil replacement

- a. Place an oil pan under the final gear case.
- b. Remove the final gear oil filler cap and the drain plug, and drain the oil.

### **WARNING:**

When draining or filling, take care not to allow foreign material to enter the final gear case. Do not allow the gear oil to contact the tire and wheel.



1. Final gear drain plug

- c. Reinstall and tighten the final gear case drain plug. (See page 48 for torque specifications.)
- d. Fill the gear case to the specified level.

### Oil capacity:

Final gear case:


0.2 L (0.18 Imp qt, 0.21 US qt)

Recommended oil: See page 27


- e. Reinstall the filler cap securely.

## Air filter

1. Removal
  - a. Open the seat.
  - b. Remove the air filter case cover by removing the three screws.



- c. Pull out the element.




1. Air filter element

## 2. Cleaning method

Tap the element lightly to remove most of the dust and dirt; then blow out the remaining dirt with compressed air from the inner surface of the element. If element is damaged, replace it.





3. Reassemble by reversing the removal procedure. Check whether the element is seated completely against the case.
4. The air filter element should be cleaned at the specified intervals.

#### **CAUTION:**

The engine should never be run without the air cleaner element installed; excessive piston and/or cylinder wear may result.


#### **Front brake adjustment**

The front brake lever should be so adjusted that it has a free play of 5 ~ 8 mm (0.2 ~ 0.3 in) at the lever end.

1. Loosen the lock nut on the brake lever.
2. Turn the adjuster so that the brake lever movement at the lever end is 5 ~ 8 mm (0.2 ~ 0.3 in) before the adjuster contacts the master cylinder piston.
3. After adjusting, tighten the lock nut.

#### **NOTE:**

Check for correct play, and make sure it lever is working properly.



1. Adjuster 2. Lock nut a. 5 ~ 8 mm (0.2 ~ 0.3 in)

### **WARNING:**

A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. This air must be removed by bleeding the brake system before the motorcycle is operated. Air in the system will result in greatly diminished braking capability and can result in loss of control and an accident. Have a Yamaha dealer or other qualified mechanic inspect and bleed the system if necessary.


## Rear brake adjustment

### **WARNING:**

For the brake pedal position adjustment, be sure to proceed as follows; (It is advisable to have a Yamaha dealer or other qualified mechanic make this adjustment).

1. Pedal height
  - a. Loosen the lock nuts.
  - b. By turning the adjuster clockwise or counterclockwise, adjust the brake pedal position so that its top end is approx. 20 mm (0.8 in) below the top of the footrest.
  - c. Secure the lock nuts.





- |                                |   |
|--------------------------------|---|
| 1. Adjuster (for pedal height) | 4. Pedal height<br>20 mm (0.8 in)         |
| 2. Lock nut                    | 5. Free play 20 ~ 30 mm<br>(0.8 ~ 1.2 in) |
| 3. Footrest                    |   |


### **WARNING:**

After adjusting the pedal height, the brake pedal free play should be adjusted.

## 2. Free play

The rear brake should be adjusted to suit the rider's preference, but free play at the end of the brake pedal should be 20 ~ 30 mm (0.8 ~ 1.2 in).

To adjust, turn the adjuster on the brake rod clockwise to reduce play; turn the adjuster counterclockwise to increase play.



1. Adjuster

### **WARNING:**

Always check brakelight operation after rear brake adjustment.


## Checking the front brake pads and rear brake shoes

A wear indicator is attached to each brake to facilitate brake pad and shoe check.

This indicator permits a visual check without disassembling the pads.

### Front:


To check, look at the pad wear indicator in back of the caliper. If any pad is worn to the wear limit, ask a Yamaha dealer or other qualified mechanic to replace the pads.



1. Wear indicator

### Rear:

To check, see the wear indicator position while depressing the brake pedal. If the indicator reaches the wear limit line, ask a Yamaha dealer or other qualified mechanic to replace the shoes.



1. Wear limit

2. Wear indicator



### Inspecting the brake fluid level

Insufficient brake fluid may allow air to enter the brake system, possibly causing the brakes to become ineffective.


Before riding, check the brake fluid level with computerized monitor system and replenish when necessary, and observe these precautions:

1. Use only the designated quality brake fluid; otherwise, the rubber seals may deteriorate, causing leakage and poor brake performance.

Recommended brake fluid: DOT #3

2. Refill with the same type of brake fluid; mixing fluids may result in a harmful chemical reaction and lead to poor performance.

3. Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point and may result in vapor lock.
4. Brake fluid may erode painted surfaces or plastic parts. Always clean up spilled fluid immediately.
5. Have a Yamaha dealer or other qualified mechanic check the cause if the brake fluid level goes down.



1. "LOWER" level


## Brake fluid replacement

1. Complete fluid replacement should be done only by trained Yamaha service personnel.
2. Complete fluid replacement should be done whenever the caliper cylinder or master cylinder is disassembled, or the fluid becomes seriously contaminated.
3. Have your Yamaha dealer or other qualified mechanic replace the following components at the specified intervals or whenever they are damaged or leaking.
  - a. Replace all brake seals every two years.
  - b. Replace all brake hoses every four years.

## Brake light switch adjustment

The brake light switch is operated by the movement of the brake pedal.

To adjust, hold the switch body with the hand so it does not rotate and turn the adjusting nut. Proper adjustment is achieved when the brake light comes on slightly before brake begins to take effect.



1. Main body

2. Adjusting nut



## Clutch adjustment

This model has two clutch cable length adjusters. The cable length adjusters are used to take up slack from cable stretch and to provide sufficient free play for proper clutch operation under various operating conditions.


### 1. Free play adjustment

The clutch should be adjusted to suit rider preference within a 2 ~ 3 mm (0.08 ~ 0.21 in) free play at the lever pivot side.


Loosen either the handlebar lever adjuster lock nut or the cable length adjuster lock nut. Next, turn the cable length adjuster either in or out until proper lever free play is achieved.

Clutch lever free play:

2 ~ 3 mm (0.08 ~ 0.12 in)



1. Lock nut 2. Adjuster a. 2 ~ 3 mm (0.08 ~ 0.12 in)



1. Lock nut 2. Adjuster

## Cable inspection and lubrication

### **WARNING:**

Damage to the outer housing of the various cables, may cause corrosion and often free movement will be obstructed. An unsafe condition may result so replace such cables as soon as possible.

Lubricate the inner cable and the cable end. If they do not operate smoothly, ask a Yamaha dealer or other qualified mechanic to replace them.

#### Recommended lubricant:

Yamaha chain and cable lube  
or SAE 10W30 motor oil

## Throttle cable and grip lubrication

The throttle twist grip assembly should be greased when the cable is lubricated, since the grip must be removed to get at the end of the throttle cable. Two screws clamp the throttle housing to the handlebar. Once these two are removed, the end of the cable can be held high to pour in several drops of lubricant. With the throttle grip disassembled, coat the metal surface of the grip assembly with a suitable all-purpose grease to cut down friction.

## Brake pedal shaft

Apply Yamaha chain and cable lube or SAE 10W30 motor oil to the brake pedal shaft.

## Change pedal/Brake and clutch lever

Lubricate the pivoting parts of each lever and pedal.

#### Recommended lubricants:

Yamaha chain and cable lube  
or SAE 10W30 motor oil



### Center and sidestand pivots

Lubricate the center and sidestand at their pivot points.


#### Recommended lubricants:

Yamaha chain and cable lube  
or SAE 10W30 motor oil

### Footrest adjustment

#### Right

1. Loosen the lock nuts and self-locking nut.



1. Lock nut

2. Self-locking nut


2. Move the footrest either way to suit the

rider's preference. (Six possible positions only) Then secure the self-locking nut.

#### Tightening torque:

55 Nm (5.5 m·kg, 40 ft·lb)

3. By turning the adjuster clockwise or counterclockwise, adjust the brake pedal position so that its top end is approx. 20 mm (0.8 in) below the top of the footrest.
4. Secure the lock nuts.



1. Adjuster  
(For pedal height)
2. Lock nut
3. Footrest


4. Pedal height 20 mm (0.8 in)
5. Free play 20 ~ 30 mm  
(0.8 ~ 1.2 in)

## WARNING:

After adjusting the pedal height, the brake pedal free play should be adjusted.

### Left

1. Loosen the lock nuts and bolt.



1. Lock nut 2. Bolt


2. Move the footrest either way to suit the rider's preference. Then secure the bolt.

Tightening torque:

55 Nm (5.5 m•kg, 40 ft•lb)

3. By turning the adjuster clockwise or counterclockwise, adjust the position of the change pedal so that its peg center is approx. 20 mm (0.8 in) below the top of the footrest.

4. Secure the lock nuts.




1. Adjuster 3. Footrest  
(For pedal height) 4. Pedal height 20 mm (0.8 in)  
2. Lock nut

## NOTE:

Viewed from the top, both adjusted footrests must be in line with each other.







## Handlebar adjustment

### 1. Vertical adjustment



Remove the switch lead holding plate, cap, two bolts and pull the grip bar as far either up or down by one notch from the standard position. (Three possible positions only)



- |                          |                        |
|--------------------------|------------------------|
| 1. Cap                   | 3. Grip bar pinch bolt |
| 2. Grip bar stopper bolt | 4. Standard position   |

## 2. Horizontal adjustment

Remove the handlebar cover, bolt cap, handlebar stopper bolt, and pinch bolt. Next pull the handlebar as far away from the handle crown as necessary to permit adjustment. Adjust the handlebar either back or forward by one notch from the standard position. (Three possible positions only)



- |                           |                         |
|---------------------------|-------------------------|
| 1. Cap                    | 3. Handlebar pinch bolt |
| 2. Handlebar stopper bolt | 4. Standard position    |

### **WARNING:**

Never tamper with this adjustment device in an attempt at further adjustment. Otherwise, it may cause:

The handlebar to contact the fuel tank or cables to be pulled loose, and the rider to assume an inappropriate riding position. Always adjust the handlebars on each side to the same position. Uneven adjustment will cause an improper riding position.



### 3. Reinstall the handlebars.

#### Tightening torque:

Grip bar stopper bolt:

16 Nm (1.6 m·kg, 11 ft·lb)

Grip bar pinch bolt:

16 Nm (1.6 m·kg, 11 ft·lb)

Handlebar stopper bolt:

23 Nm (2.3 m·kg, 17 ft·lb)

Handlebar pinch bolt:

30 Nm (3.0 m·kg, 22 ft·lb)

#### **WARNING:**


After the above adjustment, tighten all bolts using a torque wrench. If a torque wrench is not available, have a Yamaha dealer or other qualified mechanic adjust and torque the handlebars to specification.

### Front fork oil change


#### **WARNING:**

1. Fork oil leakage can cause loss of stability and unsafe handling. Have any problem corrected before operating the motorcycle.
2. Securely support the motorcycle so there is no danger of it falling over.

1. Raise the motorcycle or remove the front wheel so that there is no weight on the front end of the motorcycle.
2. Remove the handlebar cover and handlebars.



3. Remove the air valve cap from the left fork.
4. Keep the valve open while pressing it for several seconds so that the air can be let out of the inner tube.




1. Push

5. Remove the damping adjusters from the cap-bolt assembly.

#### NOTE:


Before removing the damping adjuster, align the numeral "1" with the mark in the handle crown. This serves to jog your memory in re-installation.





1. Damping adjuster      2. Set position

6. Loosen the pinch bolts and remove the cap-bolts assembly from the inner fork tubes.



1. Cap-bolt assembly      2. Pinch bolt


### **WARNING:**

The cap-bolt assembly is furnished with a damping adjustment knob. When removing and reinstalling the cap-bolt assembly, take care not to bend or otherwise damage the adjusting rod; otherwise, it may cause faulty front fork operation.

7. Place an open container under each drain hole. Remove the drain screw from each outer tube.

### **WARNING:**

Do not allow oil to contact the disc brake components. If any oil should contact the brake components, it must be removed before the motorcycle is operated. Oil will cause diminished braking capacity and will damage the rubber components of the brake assembly.



1. Drain screw

8. When most of the oil has drained, slowly raise and lower the outer tubes to pump out the remaining oil.
9. Inspect the drain screw gasket. Replace if damaged. Reinstall the drain screw.
10. Pour the specified amount of oil into the fork inner tube.


Front fork oil (each fork):  
 257 cm<sup>3</sup> (9.0 Imp oz, 8.7 US oz)  
 Yamaha Fork Oil 10wt or equivalent

11. After filling, slowly pump the forks up and down to distribute the oil.
12. Inspect the O-ring on the cap-bolt assembly. Replace O-ring if damaged.
13. Reinstall the cap-bolts assembly, damping adjusters, and tighten the pinch bolts.

#### **CAUTION:**

To tighten the cap-bolt assembly, first make sure the damper adjusting rod fits correctly in the semicircular hole in the top of the damper rod. If the adjusting rod is put in the wrong way, the cap-bolt assembly will not touch the fork collar. If so, turn the cap-bolt assembly until it falls and touches the collar, then you will be able to screw the cap-bolt assembly on. Do not force the cap-bolt assembly, your may damage the adjusting rod and ruin the unit.





1. Cap-bolt assembly      2. Collar

Tightening torque:

Cap-bolt assembly:

30 Nm (3.0 m·kg, 22 ft·lb)


Pinch bolt:

20 Nm (2.0 m·kg, 14 ft·lb)

14. Reinstall the handlebars and handlebar cover.

**WARNING:**

When installing the handlebars, align the punched mark on the handlebar with the corresponding one on the handlebar boss.



1. Punch mark (Standard position)

Tightening torque:

Handlebar stopper bolt:

23 Nm (2.3 m·kg, 17 ft·lb)

Handlebar pinch bolt:

30 Nm (3.0 m·kg, 22 ft·lb)

15. Fill the fork with air using a manual air pump or other pressurized air supply. Refer to "Front fork and rear shock absorber adjustment" for proper air pressure adjusting.

Maximum air pressure:

118 kPa (1.2 kg/cm<sup>2</sup>, 17 psi)

Do not exceed this amount.

## Front fork and rear shock absorber adjustment

### CAUTION:

Don't dent the air chamber nor damage the air hose. It will result in an air leakage.

### WARNING:

Any adjustment except for air pressure and damping, or any replacement must be performed by a Yamaha dealer or other qualified mechanic.

## Front fork:

### NOTE:

Since the right and left front forks are connected by air hose, there is only one valve where the air pressure is measured and adjusted.

#### 1. Air pressure

- Elevate the front wheel by placing the motorcycle on the centerstand.

### NOTE:

When checking and adjusting the air pressure, there should be no weight on the front end of the motorcycle.

- Remove the air valve cap.
- Using the air check gauge, check and adjusted the air pressure.  
If the air pressure is increased, the suspension becomes stiffer and if decreased, it becomes softer.




**To increase:**

Use a manual air pump or other pressurized air supply.

**To decrease:**

Release the air by pushing the valve pin.



1. Air check gauge

**NOTE:**

An optional air check gauge is available. Please ask your nearby Yamaha dealer.

P/No. 2X4-2811A-00

**Standard air pressure:**

39.2 kPa (0.4 kg/cm<sup>2</sup> , 5.7 psi)

**Maximum air pressure:**

118 kPa (1.2 kg/cm<sup>2</sup> , 17 psi)

**Minimum air pressure:**

39.2 kPa (0.4 kg/cm<sup>2</sup> , 5.7 psi)

**WARNING:**


Never pressurize the front fork above the maximum or below the minimum air pressure. It will cause damage to front fork and/or loss of motorcycle control.

- d. Install the air valve cap.
2. Damping
  - a. Turn the damping adjuster to increase or decrease the damping.
  - b. If the damping adjuster is turned toward the "4", the damping becomes harder; if the adjuster is turned toward the "1", damping becomes softer.

Standard position — No. 1

No. 1 — Minimum damping

No. 4 — Maximum damping



1. Damping adjuster

2. Standard position

### **WARNING:**

Always adjust the front forks on each side to the same position. Uneven adjustment will cause an improper riding position.

### Rear shock absorber:

### **WARNING:**


Always adjust the shock absorbers on each side to the same position. Uneven adjustment will cause an improper riding position.

#### 1. Spring preload

If the spring seat is raised, the spring becomes stiffer and if lowered, it becomes softer.

Standard position — A

A. position — Softest, E. position — Stiffest





## 2. Damping force

Turn the damping adjuster by your fingers to increase or decrease the damping. If it is difficult to turn it with your fingers, use a screw driver.


Standard position — No. 1

No. 1 — Minimum damping

No. 4 — Maximum damping

### NOTE: \_\_\_\_\_

When adjusting the damping, the adjuster should be placed in the clicked position. If not, the damping will be set to the maximum (No. 4).



1. Damping adjuster

# **Recommended combinations of the front fork and the rear shock absorber.**

Use this table as guidance to meet specific riding conditions and motorcycle load.

Front fork		Rear shock absorber		Loading condition			
Air pressure	Damping adjuster	Spring seat	Damping adjuster	Solo rider	With passenger	With accessory equipments	With accessory equipments and passenger
39.2 ~ 78.5 kPa (0.4 ~ 0.8 kg/cm <sup>2</sup> , 5.7 ~ 11 psi)	1	A ~ C	1	○			
	2	A ~ C	2	○	○		
	3	C ~ E	3		○	○	
78.5 ~ 118 kPa (0.8 ~ 1.2 kg/cm <sup>2</sup> , 11 ~ 17 psi)	4	E	4			○	○



## Steering inspection


Periodically inspect the condition of the steering. Worn out or loose steering bearings may be dangerous.

Place a block under the engine to raise the front wheel of the motorcycle off the ground: then hold the lower end of the front fork and try to move it forward and backward. If any free play can be felt, ask a Yamaha dealer or other qualified mechanic to inspect and adjust the steering assembly.

Inspection is easier if the front wheel is removed.

### **WARNING:**

Securely support the motorcycle so there is no danger of it falling over.



## Wheel bearings

If the wheel bearings in the front or rear wheel allow play in the wheel hub, or if the wheel does not turn smoothly, have a Yamaha dealer or a qualified mechanic inspect the wheel bearings. The wheel bearings should be inspected according to the General Maintenance Schedule.

## Battery

Check the level of the battery fluid and see if the terminals are tight. Add distilled water if the fluid level is low.

### CAUTION:

When inspecting the battery, be sure the breather pipe is routed correctly. If the vent tube touches the frame or exits in such a way as to cause battery electrolyte or gas to exit onto the frame, structural and cosmetic damage to the motorcycle can occur.

### WARNING:

Battery electrolyte is poisonous and dangerous, causing severe burns, etc. It contains sulfuric acid. Avoid contact with skin, eyes or clothing.

Antidote:

EXTERNAL — Flush with water.

INTERNAL — Drink large quantities of water or milk. Follow with milk of magnesia, beaten

egg or vegetable oil. Call physician immediately.

**Eyes:** Flush with water for 15 minutes and get prompt medical attention. Batteries produce explosive gases. Keep sparks, flame, cigarettes, etc. away. Ventilate when charging or using in closed space. Always shield eyes when working near batteries.

**KEEP OUT OF REACH OF CHILDREN.**

### Replenishing the battery fluid

A poorly maintained battery will deteriorate quickly. The battery fluid should be checked at least once a month.

1. The level should be between the upper and lower level marks. Use only distilled water if refilling is necessary.


### CAUTION:

Normal tap water contains minerals which are harmful to a battery; therefore, refill only with distilled water.




**CAUTION:**

Install the battery sensor into 3RD hole from positive terminal.



1. Upper level

2. Lower level



1. Battery

2. Battery sensor

2. When the motorcycle is not to be used for a month or longer, remove the battery and store it in a cool, dark place. Completely recharge the battery before reusing.
3. If the battery is to be stored for a longer period than the above, check the specific gravity of the fluid at least once a month and recharge the battery when it is too low.
4. Always make sure the connections are correct when putting the battery back in the motorcycle.  
Make sure the breather pipe is properly connected and is not damaged or obstructed.


**CAUTION:**

Make sure that the connection to the battery is correct; otherwise, damage to the micro-computer may occur.

## Headlight


This motorcycle is equipped with a quartz bulb headlight. If the headlight bulb burns out, replace the bulb as follows:

1. Headlight bulb replacement
  - a. Remove the 2 screws holding the light unit assembly to the headlight body.




1. Holding screw

- b. Disconnect the lead wires and remove the light unit assembly.



- c. Turn the bulb holder counterclockwise and remove the defective bulb.






- d. Slip a new bulb into position and secure it with the bulb holder.

**CAUTION:**

Avoid touching the glass part of the bulb. Also keep it free from oil stains; otherwise, the transparency of the glass, life of the bulb, and luminous flux will be adversely affected. If the glass is oil stained, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.

**WARNING:**

Keep flammable products or your hands away from the bulb while it is on, because it heats up. Do not touch the bulb until it cools down.



- e. Reinstall the light unit assembly to the headlight body. Adjust the headlight beam if necessary.

## 2. Headlight beam adjustment


### a. Horizontal adjustment:

To adjust the beam to the left, turn the adjusting screw clockwise.

To adjust the beam to the right, turn the screw counterclockwise.

### b. Vertical adjustment:


To adjust the beam to the upper, turn the adjusting screw clockwise to adjust the beam to the lower, turn the adjusting screw counterclockwise.



a. Horizontal adjusting screw    b. Vertical adjusting screw

## Fuse replacement

1. The fuse block is located under the seat.



1. Spare fuse

2. If any fuse is blown, turn off the ignition switch and the switch in the circuit in question and install a new fuse of proper amperage.

Then turn on the switches, and see if the electrical device operates. If the fuse immediately blows again, consult a Yamaha dealer or other qualified mechanic.



## **WARNING:**


Do not use fuses of a higher amperage rating than those recommended. Substitution of a fuse of improper rating can cause extensive electrical system damage and possible fire.

### **Auxiliary low beam light**

This motorcycle is equipped with a quartz bulb of auxiliary low beam light.

If the auxiliary low beam light bulb burns out, replace the bulb as follows:

1. Auxiliary low beam light bulb replacement.
  - a. Remove the screw holding the light unit assembly to the auxiliary low beam light body.




1. Holding screw

- b. Disconnect the lead wires and remove the light unit assembly.



- c. Unhook the bulb retaining clip and remove the clip.



1. Bulb retaining clip


- d. Remove the defective bulb and slip a new bulb into position.

**CAUTION:**

Avoid touching the glass part of the bulb. Also keep it free from oil stains; otherwise, the transparency of the glass, life of the bulb and illuminous flux will be adversely affected. If the glass is oil stained, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.


**WARNING:**

Keep flammable products or your hands away from the bulb while it is on, because it heats up. Do not touch the bulb until it cools down.



- e. For reassembly, follow the procedure below with care;
- 1) Make sure the projecting portions of the bulb holder are positioned correctly.





1. Projecting portion 2. Bulb 3. Bulb holder

2) Adjust the auxiliary low beam light beam.


2. Auxiliary low beam light beam adjustment.

**CAUTION:**


It is advisable to have a Yamaha dealer or other qualified mechanic make this adjustment.

### Front wheel removal


1. Place the motorcycle on the centerstand.
2. Remove the speedometer cable holder securing bolts.



3. Remove the front fender securing bolts and remove the fender.



4. Remove the cotter pin and wheel axle nut.
5. Loosen the pinch bolt securing the axle.



1. Pinch bolt

6. Remove the axle shaft and the front wheel. In this case, make sure the motorcycle is properly supported.




#### NOTE:


Do not depress the brake lever when the wheel is off the motorcycle as the brake pads will be forced to shut.



7. Lower the wheel until the brake discs come off the calipers. Turn the calipers outward so they do not obstruct the wheel, and remove the wheel.



8. For reassembly, follow the procedure below with case;
- Make sure the projecting portion (torque stopper) of the speedometer housing is positioned correctly.



1. Torque stopper

- Tighten the axle nut and install a new cotter pin.

Axle nut torque:


110 Nm (11 m·kg, 80 ft·lb)

**WARNING:**

Always use a new cotter pin on the axle nut.

- c. Install the front fender.
- d. Install the speedometer cable holder securing bolts.
- e. Before tightening the pinch bolt, compress the front forks several items to make sure of proper fork operation.

With the axle pinch bolt loose, wark the right fork leg back and forth until the proper clearance between the disc and caliper bracket on the front is obtained.



- f. Tighten the axle pinch bolt.

Axle pinch bolt torque:  
20 Nm (2.0 m·kg, 14 ft·lb)


### Rear wheel removal

#### **CAUTION:**

It is advisable to have a Yamaha dealer or other qualified mechanic make this removal and reassembly.


1. Place the motorcycle on the centerstand.
2. Remove the tension bar and the brake rod from the brake shoe plate. The tension bar can be removed by removing the cotter pin and nut from the tension bar bolt. The brake rod can be removed by removing the adjuster.






1. Adjuster    2. Brake rod    3. Tension bar


3. Remove the axle nut cotter pin and axle nut. Discard the old pin.




4. Loosen the rear axle pinch bolt and pull out the rear axle.



1. Pinch bolt



5. Move the wheel to the right side to separate it from the final gear case and remove the rear wheel.




6. To install the rear wheel, reverse the removal procedure.

**NOTE:**

Before installing the rear wheel, apply light coating of lithium base grease to final gear case splines and rear wheel hub splines.

When installing the rear wheel, be sure the splines on the wheel hub fit into the final gear case.



7. Tighten the axle nut, axle pinch bolt, and install a new cotter pin.

**WARNING:**

Always use a new cotter pin on the axle nut.

**Tightening torque:**

Axle nut:

110 Nm (11 m·kg, 80 ft·lb)

Axle pinch bolt:

6 Nm (0.6 m·kg, 4.3 ft·lb)



8. Adjust the rear brake. See page 55.

#### **Carburetor adjustment:**

The carburetor is a vital part of the engine and its emission control system. Adjustment should be left to a Yamaha dealer or other qualified mechanic with the professional knowledge, specialized data and equipment to do so properly.

#### **Troubleshooting**


Although Yamaha motorcycles are given a rigid inspection before shipment from the factory, trouble may occur during operation. If this happens, check the motorcycle in accordance with the procedures given in the following chart. If repair is necessary, ask a qualified mechanic such as your Yamaha dealer for assistance. The skilled technicians at your Yamaha dealer are trained and equipped to perform the necessary maintenance and repair work. For replacement parts, Yamaha recommends you use Genuine Yamaha Parts or parts you know are equivalent in quality.

Any problem in the fuel, compression or ignition system can cause poor starting, excessive emissions, engine damage, or loss of power while riding. The troubleshooting chart describes a quick and easy series of system checks to locate the problem.

## Troubleshooting chart

### WARNING:

Never check the fuel system while smoking or in the vicinity of an open flame.





# CLEANING AND STORAGE

## A. CLEANING

Frequent through cleaning of your motorcycle will not only enhance its appearance but will improve general performance and extend the useful life of many components.

1. Before cleaning the motorcycle:
  - a. Block off end of exhaust pipe to prevent water entry; a plastic bag and strong rubber band may be used.
  - b. Make sure spark plugs and gas cap are properly installed.
2. If engine case is excessively greasy, apply degreaser with a paint brush. Do not apply degreaser to wheel axles.
3. Rinse dirt and degreaser off with a garden hose, using only enough hose pressure to do the job.

## CAUTION:

---

Excessive hose pressure may cause water seepage and contamination of wheel bearings, front forks, brake calipers, and transmission seals. Many expensive repair bills have resulted from improper use of high pressure detergent applications such as those available in coin-operated car washes.

---

## CAUTION:

---

The instrument panel mustn't be subjected to any water splashes or steam from underneath.

---

4. Once the majority of the dirt has been hosed off, wash all surfaces with warm water and mild, detergent-type soap. An old tooth brush or bottle brush is handy to reach hard-to-get-to places.

5. Rinse motorcycle off immediately with clean water and dry all surfaces with a chamois, clean towel, or soft absorbent cloth.
6. Chrome-plated parts such as handlebars, fenders, forks, etc., may be further cleaned with automotive chrome cleaner.
7. Clean the seat with a vinyl upholstery cleaner to keep the cover pliable and glossy.
8. Automotibe-type wax may be applied to all painted and chrome-plated surfaces. Avoid combination cleaner-waxes. Many contain abrasives which may mar paint or protective finish on the fuel tank and side covers.
9. After finishing, start the engine immediately and let it idle for several minutes.

## B. STORAGE

Long term storage (60 days or more) of your motorcycle will require some preventive procedures to insure against deterioration. After cleaning the machine thoroughly, prepare for storage as follows:

1. Drain fuel tank, fuel lines, and carburetor float bowl.
2. Remove the empty fuel tank, pour a cup of SAE 10W30 or SAE 20W40 motor oil in tank, shake the tank to coat the inner surfaces thoroughly and drain off excess the oil. Reinstall the tank.
3. Remove the spark plug, pour about one tablespoon of SAE 10W30 or SAE 10W40 motor oil in the spark plug hole and reinstall the spark plug. Crank the engine over several times (ground spark plug lead wires) to coat the cylinder walls with oil.



**WARNING:**

When using starter motor to crank the engine, remove spark plug wires and ground them to prevent sparking.

4. Lubricate all control cables.
5. Block up the frame to raise both wheels off the ground.
6. Tie a plastic bag over the exhaust pipe outlet to prevent moisture entering.
7. If storing in humid or salt-air atmosphere, coat all exposed metal surfaces with a light film of oil. Do not apply oil to any rubber parts or the seat cover.
8. Remove the battery and charge it. Store it in a dry place and recharge it once a month. Do not store the battery in an excessively warm or cold place (less than 0°C (32°F) or more than 30°C (86°F)).

**NOTE:**

Make any necessary repairs before storing the motorcycle.

## Consumer information

# MISCELLANEOUS

## STOPPING DISTANCE

These figures indicate braking performance that can be met or exceeded by the vehicles to which they apply, without locking the wheels, under different conditions of loading and with partial failures of the braking system. The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.

Description of vehicles to which this table applies: Yamaha motorcycle XJ750J

A. Fully Operational Service Brake

Load

Light

159

Maximum

184

### NOTE:

The statement above is required by U.S. Federal law. "Partial failures" of the braking system do not apply to this chart.

0 100 200 300 (Feet)

Stopping distance in feet from 60 mi/h



# SPECIFICATIONS

## General specifications

MODEL	XJ750J
<b>Dimension:</b> Overall length Overall width Overall height Wheelbase Minimum road clearance	2,145 mm (84.4 in) 830 mm (32.7 in) 1,175 mm (46.3 in) 1,445 mm (56.9 in) 135 mm ( 5.3 in)
<b>Basic weight:</b> With oil and full fuel tank	236 kg (520 lb)
<b>Performance:</b> Minimum turning radius	2,600 mm (102.4 in)
<b>Engine:</b> Type Engine model Cylinder Displacement Bore x Stroke Compression ratio Starting system Ignition system	4 stroke, gasoline, air-cooled DOHC 15R Forward incline 4 cylinder 748 cm <sup>3</sup> (45.64 cu.in) 65.0 x 56.4 mm (2.559 x 2.220 in) 9.2 : 1 Electric starter Battery ignition (Full transistor ignition)

MODEL	XJ750J
Fuel tank capacity	Total amount: 3.5 L (3.1 Imp qt, 3.7 US qt)
Engine oil quantity	Periodic oil charge: 2.5 L (2.2 Imp qt, 2.6 US qt)
	With oil filter replacement: 2.8 L (2.5 Imp qt, 3.0 US qt)
	With oil filter replacement: 0.0 L (0.0 Imp qt, 0.0 US qt)
Lubrication system	Wet sump
Battery type/capacity	YB14L/12V, 14AH
Generator	A.C. magneto
Spark plug	BP7ES (NGK), W22EP (NIPPONDENSO)
Carburetor	HSC32 x 4
Air cleaner	Dry type element
Clutch type	Wet, multiple-disc
Transmission:	
Primary reduction system	Gear
Primary reduction ratio	97/58 (1.672)
Secondary reduction system	Shaft
Secondary reduction ratio	$48/37 \times 19/18 \times 32/11 = 3.983$
Gear box type	Constant mesh, 5-seped forward
Operation system	Left foot operation



MODEL		XJ750J
Gear ratio:	First	35/16 (2.187)
	Second	30/20 (1.500)
	Third	30/26 (1.153)
	Fourth	28/30 (0.933)
	Fifth	26/32 (0.812)
Chassis:		
Frame type		Tubular steel, double cradle
Steering:	Caster	29°
	Trail	124 mm (4.88 in)
Tire size:	Front	3.25H19-4PR Tubeless tire
	Rear	130/90-16 67H Tubeless tire
Braking system:	Front	Disc brake/Right hand operation
	Rear	Drum brake/Right foot operation
Suspension:	Front	Telescopic fork
	Rear	Swing arm
Shock absorber:	Front	Air/coil spring, oil damper
	Rear	Coil spring, oil damper

MODEL	XJ750J
<b>Electrical:</b> Headlight Tail/brake light Flasher light Pilot lights:      TURN WARNING NEUTRAL HIGH BEAM Meter light Auxiliary low beam light	12V, 60W/55W (Quartz bulb) 12V, 8W/27W x 2 12V, 27W x 4 12V, 3.4W x 2 12V, 3.4W 12V, 3.4W 12V, 3.4W 12V, 3.4W x 2 12V, 35W



## WARRANTY INFORMATION

Please refer to your copy of the Yamaha Owner's Warranty Guide\* for details of the warranty offered on your new Yamaha.

The Warranty Guide contains the warranty policy, an explanation of the warranty, and other important information. Becoming familiar with these policies will be to your advantage in making the best use of Yamaha's warranty programs.

There are certain requirements which you must meet in order to qualify for warranty coverage. FIRST, your new Yamaha must be operated and maintained properly, as, explained in this manual. If you have any questions about any procedure in this manual, please consult your dealer. ABUSE AND NEGLECTED MAINTENANCE MAY LEAD TO MECHANICAL FAILURES WHICH CANNOT BE COVERED UNDER WARRANTY.

SECOND, IF ANY PROBLEMS OCCUR WHICH YOU FEEL SHOULD BE COVERED UNDER WARRANTY, NOTIFY YOUR DEALER IMMEDIATELY. Don't delay, as small problems left unrepaired can become large problems which may not be covered under warranty.

We recommend that the Warranty Guide be used as a folder in which you may keep your registration and other important documents related to your new Yamaha.

\* The Yamaha Owner's Warranty Guide is to be supplied by your Yamaha dealer at the time of purchase. If you did not receive one, or have lost yours, you may obtain extra copies upon request from your Yamaha dealer or by writing to:

YAMAHA MOTOR CORPORATION, U.S.A.  
P.O. Box 6555, Katella Avenue  
Cypress, California 90630  
Attn: Warranty Department

## MAINTENANCE RECORD

Copies of work orders and/or receipts for parts you purchase and install will be required to document maintenance done in accordance with the emission warranty. The chart below is printed only as a reminder to you that the maintenance work is required. It is not acceptable proof of maintenance work.

MAINTENANCE INTERVAL	DATE OF SERVICE	MILEAGE	SERVICING DEALER NAME AND ADDRESS	SERVICING DEALER SIGNATURE
1,000 km or 600 mi or 1 mo.				
5,000 km or 3,000 mi or 7 mo.				
9,000 km or 5,600 mi or 13 mo.				
13,000 km or 8,100 mi or 19 mo.				
17,000 km or 10,600 mi or 25 mo.				



MAINTENANCE INTERVAL	DATE OF SERVICE	MILEAGE	SERVICING DEALER NAME AND ADDRESS	SERVICING DEALER SIGNATURE
21,000 km or 13,000 mi or 31 mo.				
25,000 km or 15,500 mi or 37 mo.				
29,000 km or 18,000 mi or 43 mo.				
33,000 km or 20,500 mi or 49 mo.				
37,000 km or 23,000 mi or 55 mo.				
41,000 km or 25,500 mi or 61 mo.				

# WIRING DIAGRAM

## COLOR CODE

L..... Blue	W/G..... White/Green
O..... Orange	Br/W..... Brown/White
Br..... Brown	L/B..... Blue/Black
B..... Black	W/Y..... White/Yellow
Dg..... Dark green	G/Y..... Green/Yellow
Y..... Yellow	W/R..... White/Red
Sb..... Sky blue	G/L..... Green/Blue
Ch..... Chocolate	L/W..... Blue/White
G..... Green	W/B..... White/Black
R..... Red	Y/R..... Yellow/Red
P..... Pink	Y/G..... Yellow/Green
Gy..... Gray	L/Y..... Blue/Yellow
W..... White	B/Y..... Black/Yellow
R/W..... Red/White	B/R..... Black/Red
R/Y..... Red/Yellow	G/R..... Green/Red
	B/W..... Black/White



